



ELECTRICAL RISER

**DOOR SCHEDULE NOTES:**

1. USE 4-7/8 ANSI STRIKE PREP ON FRAME.
2. ELIMINATE MORTAR BOX FOR STRIKE ON STEEL FRAMES.

**ELECTRICIAN NOTES:**

1. INSTALL PULL WIRE OR RACEWAY IN WALL CAVITY FROM ELEC. STRIKE TO RECESSED CEILING.
2. INSTALL PULL WIRE IN WALL CAVITY FROM FLOOR ACTUATOR LOCATION TO RECESSED CEILING. (FLOOR ACTUATOR MOUNTS FLUSH TO WALL WITHOUT J-BOX) LEAVE PULL WIRE HANG OUT LEVEL WITH FINISHED FLOOR.
3. LOCATE 120V J-BOX ABOVE RECESSED CEILING OVER DOOR FOR AUTO OPERATOR POWER.



Clean Door Systems

1200 79 1/2 Street Minneapolis, MN 55386  
 PH: (866) 44-Doors www.cleandoor.com

